



**Low Cost LT1/LS1 Mass [Airflow Sensor](#)
Installation Instructions (Read Carefully Before Starting Project)**

1. Disconnect the negative battery cable.
2. Remove the factory sensor from the airbox by removing the two hose clamps and disconnecting the electrical connector.
3. Now install the Granatelli Motor Sports air sensor into the same location, be sure to install with the flow arrow pointing towards you engine.
4. Using the supplied coupler & clamp, join your new GMS sensor to the GMS High Flow Air Lid (Part#350201 or #350200) or the stock, highly restrictive, power robbing air box.
5. Tighten the clamps & Connect the electrical connector, it should be installed so that the PED writing on the connector is on the opposite side of the plastic clip.
6. Re-connect the negative cable, your install is complete!