



## 1980 TOYOTA

### Supplement Instruction Form 3-T

1. After having completed Step No. 6, before installing [custom hub](#), note that some models have a new turn signal cam with three (3) locator pins. Therefore, you cannot use the existing vertical slots on back of custom hub for locating cam.
2. Install hub onto shaft per Step No. 8. Make sure that the center pin on turn signal cam is at top center. Slide hub down shaft far enough to just touch the cam, then rotate cam about 25 degrees clockwise and push hub down until all three (3) pins position themselves around hub base. Plastic cam should rest flush against the bottom of the custom hub.
3. Continue with Step No. 9.