



DEFLECTOR MOUNTING INSTRUCTIONS

Mounting hardware kit: Push Type Retainers – 4 pcs.

- 1). Clean hood with mild soap and water and dry thoroughly.
- 2). Place the deflector on the grille shell and align the deflector mounting holes with the factory holes on the front of the grille shell. Hold the deflector firmly in place against the grille shell.

With the retainer screws backed halfway out, install the supplied push type retainers by inserting them through the deflector and into the corresponding factory holes. With a phillips screwdriver, screw or push the center of the retainer to fasten the deflector in place. *(SEE ILLUSTRATION)*

