

# INSTALL INSTRUCTIONS

## C-DMM-2011 Dash Monitor Mount

### 2009-2014 Ford F-150

**Notes:**

1. *The C-DMM-2000 series Dash Monitor Mount brackets are specifically designed to work with Havis, Inc, model # TSD-101 Touch Screen Display.*
2. *The display mount bracket includes a VESA 75 hole pattern that can also be used for some light weight tablet docking station applications under 5 lbs. . Acceptable positioning must be determined by end user.*

**TOOLS REQUIRED:** *(some tools are not needed for all vehicle installations)*

- Socket set - metric & standard      • Drill & drill bits                      • Tape measure
- Phillips screwdriver                      • Trim removal tools                      • Pencil / Marker

**MOUNT BRACKET PARTS and HARDWARE:**


*Installation parts with \* come loose in hardware kit bag. Other parts are preassembled*

QTY:	DESCRIPTION:	PART #:
1	Main dash mount bracket	CM008516
1	Pivot / display mount bracket	MT-0320-SA *
1	Stop bracket	MT-0291-SM-A
1	8-32 Machine screw	GSM34077
1	Tilt swivel hinge	GSM22005
1	Tilt swivel adaptor	CM008531
1	Lower support plate	CM008511
1	PVC spacer washer	CM008582
2	1/4" x 3/4" Carriage bolts	GSM32000
2	Nylon 1/16" spacer washer	CM86600
2	1/4" Nylock nut	GSM30016
2	1/4" Flat washer	GSM31005
1	M8 hex nut SS	GSM30113
1	M8 lock washer SS	GSM31217
4	Machine Screw 10-32 x 1/2"	GSM33118
4	#10 Flat washer	GSM31003
1	Vinyl cap (.50" high x .312 - .375 id)	GSM41127
2	M5 x 10mm Thread forming screw	GSM33774
2	Pull through bumper (3mm head)	GSM21109
2	Push in bumper (10mm head)	GSM21108
1	Rubber grommet (1.5" wide)	GSM20091
1	Plastic snap grommet (1.5" wide)	GSM20017-2

**ALWAYS!**

- Read all instructions before installing any Havis, Inc products.
- Use hardware provided with install kit

C-DMM-2011 assembly






View of F-150 prior to installation.




Remove rubber cover from change tray



Remove two (2) 7mm head fasteners.  
***Set aside factory change tray.  
It will not be reused.***



Locate and remove two (2) 7mm head fasteners



Install previously removed 7mm head fasteners into lower support bracket. Install into vehicle.  
***It is recommended to run the Display harnesses up to this area now.***



Install forward fasteners using previously removed hardware from change tray.





Install dash mount bracket and run harnesses through center of support.



Install and tightened four (4) 10-32 x 1/2" machine screws and #10 washers.



Connect harnesses to the back of the TSD-101 display. It is important to also double wire tie the harnesses to provide sturdy strain relief for the plugs.  
**USB connection from remote Docking station must plug into USB plug closest to front of display.**



Attach pivot / display mount bracket to display with M4 x 0.7 x 10mm Phillips head machine screws, lock washers and flat washers. Display mount hardware is included with TSD-101 hardware kit



Attach bracket with display to the tilt swivel hinge with M8 hex nut and lock washer. Tighten nut and attach vinyl cap on M8 bolt threads.



**Refer to TSD-101 owner's manual for power and computer connection details.**

When it comes to quality car mounts & chargers, Havis is the brand you can depend on.