



## Magnetic Suction Mount Instructions - Ver 1.0



Step 1: Determine if you will adhere the 3M adhesive to the back of your phone or back of your phone case.

Step 2: Remove the protective layer from the adhesive and adhere to the case or device.

Step 3: To install the Suction Mount, remove plastic from suction. Find the desired location and adhere the suction to the window. Depress the lever to seal the suction.

Step 4: Once you have mounted the suction device, Use the round knob adjuster to select the preferred angle. At this point, you may want to place the phone on the mount to find the desired angle. Be sure to tighten this knob counter clockwise when finished.

Step 5: Height adjustability: Flip down the portion at the bottom that the cell phone will rest on, then use two fingers to release the buttons on the back to increase the height. To retract the height, depress the two buttons on back and push the bottom back into place.