



HE-DGBK1

54" Curved LED Light Bar Mount

2002-2008 Dodge Ram 1500

2003-2009 Dodge Ram 2500/3500

NOTE: Please read instructions before beginning installation. Check all of the kit's hardware to ensure it has all the proper contents. Be sure you have all needed parts and know where they go.

Contents of Kit: Drivers and passengers side brackets, (4) 3/16" rivets

Tools needed: T15 Torx bit, a Drill, 3/16" drill bit, Rivet gun, a second person (recommended)

Installation Instructions:

1. Start by opening the doors and pulling back the weather stripping from the top of the door jam on both sides of the truck.



2. Remove the factory screw using a T15 Torx bit.



3. Place the correct side light mount on the truck with the first hole lined up with the factory screw opening and attach the T15 Torx screw.



4. Use a 3/16" drill bit to drill the two remaining holes.



5. With a rivet gun, use the supplied 3/16" rivets to secure the mount to the cab.



6. Repeat the same steps for the other side of the truck.
7. Once mounts are securely in place, the light bar can now be installed. With a second person install light bar with the light bar's supplied hardware.



8. Adjustments to the light bar can now be made to achieve the desired angle and then tighten bolts down.

9. Remove the remaining T15 Torx screws holding down the plastic molding and pull away from truck.



10. Run the light bar's wire under the mount and behind the A-pillar's plastic molding.
11. Reinstall the removed T15 Torx screws to secure plastic molding and weather stripping back in the factory location.

