

Hellwig PRODUCTS

INSTALLATION INSTRUCTIONS REAR STABILIZER BAR 94-96 Impala SS RSB

Thank you for purchasing a quality Hellwig Product.
PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION



TORQUE TABLE

BOLT SIZE: 3/8" = 20-30 ft. lbs. - 7/16" = 35-45 ft. lbs. - 1/2" = 50-70 ft. lbs. - 9/16" = 70-90 ft. lbs. - 5/8" = 120 ft. lbs

SAFETY: BEFORE STARTING YOUR INSTALLATION, BE SURE TO SET PARKING BRAKE AND CHOCK TIRES.

NOTE: THIS UNIT IS DESIGNED TO REPLACE THE FACTORY INSTALLED REAR ANTI-SWAY BAR.

Hellwig PRODUCTS

1. Remove factory sway bar and attach new sway bar using factory hardware. Pay careful attention to orientation of sway bar as shown in photos.
2. Torque fasteners to factory specification.
3. Bounce vehicle a couple of times and check installation for clearance to fuel and brake lines and other components. After one week of driving recheck your installation and fastener torque. Recheck on a regular basis thereafter.