



INSTALLATION INSTRUCTIONS

Front Stabilizer Bar

05+ F-250 & F-350 4 X 2 SINGLE R/WHEEL

05+ F-350 DUALY

Thank you for purchasing a quality Hellwig Product.

PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION

TORQUE TABLE

BOLT SIZE: 3/8" = 20-30 ft. lbs. - 7/16" = 35-45 ft. lbs. - 1/2" = 50-70 ft. lbs. - 9/16" = 70-90 ft. lbs.

SAFETY: BEFORE STARTING YOUR INSTALLATION, BE SURE TO SET PARKING BRAKE AND CHOCK THE WHEELS.

**NOTE: TO EASE INSTALLATION AND TO PROPERLY ADJUST BAR, THE WEIGHT OF THE VEHICLE MUST BE ON THE SUSPENSION, AS IF DRIVING DOWN THE ROAD.
DO NOT RAISE THE VEHICLE BY FRAME.**

NOTE: THIS UNIT IS DESIGNED TO REPLACE THE FACTORY INSTALLED FRONT ANTI-SWAY BAR USING THE FACTORY END LINK ASSEMBLIES, U-PLATES AND MOUNTING HARDWARE.