Endurance replacement 7 blade connector Instructions:

- This part will work only on vehicles that have a factory 7-way connector.
- Remove plug from the back of the factory 7-way connector by pushing in on locking tabs.
- 3. Remove damaged 7-way connector
- 4. Mount the Hopkins® replacement 7-way connector by twisting into the OEM braclet.
- Apply a small amount of grease to all electrical connections to help prevent corrosion.
- 6. Plug the Hopkins® replacement 7 blade connector into the mating vehicle plug. Be sure the connectors are fully inserted with locking tabs in place.

Test all functions with engine running to ensure proper operation.