



**GD = Ground**

**LT = Left turn**

**AP = Auxiliary power lead**

- Ensure connection to fuse box or fused battery lead.

**EB = Electric brakes**

- Attach to electric brake control.

**BU = Reverse**

**TM = Tail**

**RT = Right turn**

1. This part will work only on vehicles that have a factory 7-way connector.
2. Remove plug from the back of the factory 7-way connector by pushing in on locking tabs.
3. Mount the Multi-Tow® to the factory mounting bracket.
4. Apply a small amount of grease to all electrical connections to help prevent corrosion.
5. Plug the Multi-Tow® into the mating vehicle plug. Be sure the connectors are fully inserted with locking tabs in place.
6. Test all functions with engine running to ensure proper operation.

**TIPS:**

**Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.**

A heavy duty flasher may be required to eliminate rapid flashing. Always unplug boat trailer connector before backing trailer into the water.

\* If your Nissan vehicle did not come with a factory 7- way, you must install 2 relays (#2523079945 and #2523079964), purchased from your local Nissan dealer.