



41154

For vehicles without a Factory 7 Blade Connector:

1. Locate the tow vehicle's OE harness connector located under the vehicle, behind the bumper, on the driver's side of the vehicle.
2. Remove the protective cap from OE housing and save. Be sure the mating surface of the OE housing is free of dirt and clean if necessary.
3. Insert the T-connector housing into the vehicle's housing. Be sure that the T-connector is fully inserted with locking tabs in place.
4. Place protective cap on the remaining plug end.
5. Secure excess wire to the vehicle using the provided zip-ties.

For vehicles with a Factory 7 Blade Connector:

1. Locate the factory 7 blade attached to the hitch on the driver's side.
2. Separate the factory OE harness connector and the 7 blade.
3. Insert the T-connector between the factory OE housing and the 7 blade housing. Be sure that the T-connector is fully inserted with locking tabs in place.
4. Secure excess wire to the vehicle using the provided zip-ties.