



**GD = Ground**

**LT = Left turn**

**AP = Auxiliary**

**EB = Electric brakes**

**BU = Reverse**

**TM = Tail**

**RT = Right turn**

1. This will work only on vehicles that come equipped with a factory tow 7-way connector
2. Remove plug from the back of the factory 7-way connector by pushing in on locking tabs.
3. Mount the Hopkins® Quick Install 7 blade connector to the existing vehicle mounting bracket or use Hopkins® bracket. (Part 48615, not included)
4. Apply a small amount of grease to all electrical connections to help prevent corrosion.
5. Plug the adapter harness into the 7-way connector and plug the Hopkins® connector into the mating vehicle plug. Be sure the connectors are fully inserted with locking tabs in place.
6. Test all functions with engine running to ensure proper operation.

**NOTE: Locate wires and pin location by function only. Color coding is not standard among all manufacturers.**