



**#47105**

**WIRE IDENTIFICATION**

Green	Right Turn
Yellow	Left Turn
Brown	Tail / Park
White	Ground

1. Clean mating surfaces of the Hopkins® Vehicle Connector if needed.
2. Apply grease to the terminals on the 4-wire flat harness and plug it into the vehicle connector.
3. Clean dirt and rustproofing from an area of the vehicle where you can ground the white wire with the screw provided.
4. Secure excess wire to the vehicle.
5. Plug the wire harness into the trailer and check the lighting system for proper operation with the engine running.

**TIPS:**

Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion. A heavy duty flasher may be required to eliminate rapid flashing. Always unplug boat [trailer connector](#) before backing trailer into the water.

Have trailer on ball of vehicle while testing functions

---