

# #47210

**Note:** Universal harness enables 47210 to be installed on any vehicle.

1. Locate wires on vehicle by function only.

White wire..... Ground

Yellow wire..... Left turn

Green wire ..... Right turn

Brown wire ..... Taillight

Red wire..... Auxillary power lead

Blue wire..... Electric brake

Purple wire ..... Backup / reverse

**Tip:** Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.

2. Mount The Hopkins® Quick-Install 7 Blade connector to the existing mounting bracket or use a Hopkins bracket (Part 48615, not included).
3. Plug the Hopkins® Quick-Install 7 Blade vehicle connector into mating plug. Be sure the connectors are fully inserted with locking tabs in place.