

WIRING IDENTIFICATION

WHITE	-----	GROUND
BROWN	-----	PARK/TAIL
YELLOW	-----	LEFT TURN
GREEN	-----	RIGHT TURN
BLUE	-----	BACK UP

INSTRUCTIONS:

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the “Vehicle side” colored wires on the female half (1 metal terminal exposed) to the SAME FUNCTIONS on the tow vehicle.
3. Attach the “trailer side” color wires on the male half (4 metal terminals exposed) to the trailer.
4. Plug mating parts together and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.