

#47900

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the color wires to the SAME FUNCTIONS on the tow vehicle. Attach screw to vehicle frame with screw provided.
3. Check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

TIPS:

Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.

LOCATE WIRES BY FUNCTION ONLY

White (GD) . . Ground
Yellow (LT) . . Left turn
Green (RT) . . Right turn
Brown (TM). . Tail / Marker
Blue (BK) . . . Reverse