

#47905

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the color wires to the **SAME FUNCTIONS** on the tow vehicle.
3. Check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

WIRING IDENTIFICATION

WhiteGround

YellowLeft turn

GreenRight turn

Brown.....Park / tail

Blue.....Reverse