

# #48015

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach wires to the SAME FUNCTIONS on the tow vehicle.
3. Plug into trailer and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

## WIRING IDENTIFICATION

WHITE.....GROUND

RED.....BRAKE

GREEN.....RIGHT TURN

YELLOW....LEFT TURN

BROWN.....PARK / TAIL