

#48025

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the “car side” color wires on the female half (1 metal terminal exposed) to the **SAME FUNCTIONS** on the tow vehicle.
3. Plug into trailer and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

LOCATE WIRES BY FUNCTION ONLY

White WireGround

Yellow WireLeft turn

Green Wire..... Right turn

Brown WireTaillight

Red Wire Brake

Blue Wire Auxiliary