

#48055

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the “car side” color wires on the female half (1 metal terminal exposed) to the SAME FUNCTIONS on the tow vehicle
3. Plug into trailer and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail/parking lights and operate directional signals to check right /left turn.
4. When the right turn signal is activated, the LED above “RT” on the 4-wire flat should activate. This should also be the case for the left turn (“LT”), tail marker (“TM”) and brake (“RT” and “LT”).

NOTE:

Have trailer on ball of vehicle when testing trailer functions

LOCATE WIRES BY FUNCTION ONLY

WhiteGround

Yellow..... Left turn

Green..... Right turn

Brown..... Taillight