

# #48190

1. Remove screws and splice cover
2. Insert Wires into Quick-Fix™ 4-wire flat grooves and fully insert wires into v-shaped splices.
3. Apply terminal grease to splice area.
4. Press splice cover into place and secure with screws.
5. Verify continuity of each function. LED's should illuminate upon activation.
6. Apply terminal grease to terminals. LOCATE

## WIRES BY FUNCTION ONLY

---

White ..... Ground

Yellow ..... Left turn

Green ..... Right turn

Brown ..... Taillight