

1. Remove damaged 4-wire flat.
2. Insert wires into Quick-Fix™ 4-wire flat.
3. Compress internal splices.
4. Connect vehicle to trailer and verify trailer light functions.

LOCATE WIRES BY FUNCTION ONLY

White Ground

Yellow Left turn

Green Right turn

Brown Taillight