



1. Loosen the set screw (A) on the vehicle end socket and remove the socket from housing. Route wiring through socket housing. Strip wires 1/4" and tightly secure them to socket terminals. Align socket keyway with housing key and insert socket into housing. Tighten set screw.
2. Loosen set screw (B) on the trailer end plug and remove housing. Repeat procedures in Step 1. Leave 18" of slack between tow vehicle and trailer to allow trailer to turn. Cut off excess wires.
3. Plug trailer in to vehicle and test all functions.

LOCATE WIRES BY FUNCTION ONLY

White WireGround

Yellow WireLeft turn

Green WireRight turn

Brown WireTaillight