



1. Loosen the set screw (A) on the vehicle end socket and remove the socket from housing. Route wiring through socket housing. Strip wires 1/4" and tightly secure them to socket terminals. Align socket keyway with housing key (B) and insert socket into housing. Tighten set screw.
2. Plug trailer into vehicle and test all functions.

LOCATE WIRES BY FUNCTION ONLY

White wireAttach to good ground

Yellow wireAttach to left
turn

Green wireAttach to right turn

Brown wireAttach to the taillight

Blue wireAttach to backup / reverse

Red wireAttach to auxiliary