

Trailer Hitch Wiring & Electrical

1. To expose wiring, open rear door and remove screws (use 5/16" hex drive) from both rear lamp assemblies and pull assemblies straight back.
2. Unplug connectors B to E.
3. Plug the connectors into taillight connectors B to C and D to E.
4. Reinstall the taillight assemblies. Route harness wiring out of the bottom of the lamp assemblies and behind the bumper.
5. Drill a 1/8" hole into the nearest frame channel and attach the white ground wire with screw provided.
6. Secure any loose wiring to the vehicle with the wire ties provided.
7. Apply grease to the wire harness trailer end to prevent terminal corrosion.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

