



#42635

1. Locate vehicle taillight wiring harness by removing the two right hand screws from the driver's side taillight and pulling taillight away from the body.
2. Disconnect vehicle wiring harness behind the left taillight, apply a small amount of grease to all connections, and plug the Wiring Kit into the vehicle wiring harness and into the left taillight.
3. Route the 4-wire flat over or under the frame to the center of the bumper and secure with wire ties.
4. Replace the taillight by installing the two screws removed in step 1.
5. Apply a small amount of grease to the 4-wire flat to prevent corrosion and plug into matching 4-wire flat on trailer.
6. Check all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

[Trailer Hitch Wiring & Electrical](#)