

**INSTRUCTIONS:**

1. Locate vehicle taillight wiring harness (A). This harness will have the same connector end as the Hopkins® Vehicle Wiring Kit (T-Connector). Please check for your vehicle.

ACURA CL, RL, TL and Integra – Locate connector in the trunk behind driver's side taillight access panel.

MDX – Locate connector inside rear door under carpet in the middle of the vehicle.

HONDA Accord Wagon – Locate connector inside spare tire compartment.

CRV 1997-01 – Locate connector behind driver's side rear speaker.

CRV 2002-03 – Locate connector behind driver's side rear panel.

Odyssey 1995-02 – Locate connector inside the driver's side rear quarter panel.

Odyssey 2003-04 – Locate connector inside the passenger side rear quarter panel (D).

Pilot – Locate connector under sill plate in rear of vehicle

ISUZU Oasis – Locate connector inside the driver's side rear quarter panel.

2. Remove protective cap (not required on all installations) from the vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Hopkins® Vehicle Wiring Kit (B) into mating vehicle plug. Be sure the connectors are fully inserted with locking tabs in place.
5. Plug completed wire harness (C) into the trailer connector.
6. Test all functions with engine running to ensure proper operation.

TIPS:

Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.

Converter maximum load – 2.1 amps. on left and right turn (one bulb on each side).