



WIRE CODE

White wire----- Ground

Blue wire----- Electric brake

Black wire----- Battery

Red wire----- Stop lamp switch

1. Remove storage compartment to the left of radio.
2. Remove connector (Fig. 1 / A) from back of storage compartment.
3. Plug the brake control connector into the vehicle connector (Fig. 2).
4. Plug mating end of the brake control connector into the brake control.
5. Test all functions.

Wire to brake control by function only. Color coding is not standard among all manufacturers. To ensure proper installation, read brake control instructions thoroughly.