

**Wiring identification**

White wire ..... Attach to ground

Red wire ..... Battery

1. Find a suitable location for the socket to be mounted.
2. Clean the mounting surface to ensure good adhesion.
3. **OPTIONAL:** If you wish to drill a hole behind the location of the socket for the wires to pass through, do so with a 1/2" drill bit. If drilling through metal, a rubber grommet may be desirable to protect the wire from being cut.
4. Peel the backing from the adhesive tape and press the socket to the mounting surface. If you do not drill the hole in step 3, make sure the wires from the socket pass along the channel in the tape.
5. **OPTIONAL:** If you wish to use screws for permanent mounting, insert them now.
6. Ground the white wire to a clean, rust-free spot on the vehicle frame.
7. Splice a 14-gauge red wire onto the red wire coming from the socket. Be sure this wire is long enough to reach the battery.
8. Run the wire from the socket to the battery. Avoid the exhaust system, fuel tank and drive train.  
**Important:** Use fuse to attach the wire to the positive (+) battery terminal.

**Identificacion de alambrado**

Alambre blanco ..... Conectar a tierra

Alambre rojo ..... Bateria

1. Encuentre una localizacion apropiada para montar el socket.
2. Limpie la superficie donde se va a montar para asegurar buena adhesion.
3. **OPCIONAL:** Si quiere hacer una perforacion atrás de la localizacion del socket para meter los alambres, hagalo ahora con una broca de 13 mm. Si perfora metal, un sello de hule puede ser necesario.
4. Despegue el papel protector del tape ahesivo y presione el socket en la superficie de montaje. Si Usted no perfora de acuerdo al paso 3, asegurese que los alambres del socket pasan a lo largo del canal en el tape.
5. **OPCIONAL:** Si desea usar tornillos para un montaje permanente, atornillelos ahora.
6. Aterrice el alambre blanco a un punto limpio y libre de corrosión en el chasis del vehículo.
7. Una un alambre calibre 14 con el alambre rojo que viene del socket. Este alambre debe ser tan largo que alcance la bateria.
8. Dirija el alambre del socket a la bateria. Evite el contacto con el sistema de mofles, el tanque de la gasolina y el sistema de traccion. Importante: Use el ensamble de fusible para conectar el alambre a la terminal positiva (+) de la bateria.