

## *Studded Dog Bone Conv. Kit 17366* *70-74 Mopar E-Bodies*

IMPORTANT: PLEASE READ THE ENTIRE INSTRUCTION MANUAL BEFORE STARTING THIS INSTALLATION.

### Installation

1. Remove the current Hotchkis dog bone end link from the car.



2. Press the inner sleeve out of one of the dog bone ends. (It doesn't matter which end)
3. Retain the 2 polyurethane bushings and re-grease the inside surface with the supplied silicon lube.
4. Press in the new studded sleeve into the bushings.
5. Reinstall the dog bone back onto the car. Make sure to attach the studded end onto the sway bar first. The stud should point inward towards the middle of the car. Use the provided washer and nut to secure the stud onto the sway bar. Reuse the nuts & bolts for the frame mount end.