

Sway Bar End Link Kit 25834
06-UP BMW E90-E93

Installation of Hotchkis End Links

1 *Raising Vehicle*

Jack up the vehicle at the specified factory jack points. Remove all 4 wheels to gain easy access to the end links.

2 *Remove Stock End Links*

Remove the stock end links from the car.

3 *Set Initial End Link Length*

Set the stock links next to the Hotchkis links. Adjust the Hotchkis end links to the same length as the stock units.



4 *Reinstall Hotchkis End Links*

Reinstall the Hotchkis end links in the same manner as stock removal. Make sure all hardware is fully tightened before driving the vehicle.

Slight adjustment to the length of the end links may be necessary to ensure there is no preload on the sway bars. To do this, drive the vehicle on floor ramps to access the end links from the bottom with the weight of the vehicle on the wheels. Adjust the end links until the end link inserts into the sway bar hole easily. Fully tighten all of the jam nuts and stud nuts.

If you are using our end links on an adjustable coil-over system, it is a good idea to determine ride height and/or corner balance the vehicle before setting the length of the end links. The main benefit of adjustable end links is to be able to remove any preload in the sway bars especially in an asymmetrical ride height setup typically found on corner balanced coil-over cars.