



Installation Instructions

HURST SHIFTER CABLE SUPPLEMENT

Fits: Auto Stick 3, Pistol Grip, Quarter Stick® and Quarter Stick 2

Catalog # 5000025

WORK SAFELY! For maximum safety, perform this installation on a clean, level surface and with the engine turned off. Place blocks or wedges in front of and behind both rear wheels to prevent movement in either direction.

CAUTION: To avoid any possibility of bodily injury or damage to vehicle, do not attempt installation until you are confident that the vehicle is safely secured and will not move.

1. Insert the shifter cable into the mounting bracket and secure using a clip. Push the clip onto the cable inside of the bracket with the tab facing rearward and tap in until fully seated.
2. Install the cable pivot onto the threaded end of the shifter cable. Adjust the pivot end of the cable until it slides freely into the hole in the transmission arm. Lock the adjustment by tightening the hex nut against the pivot. After inserting the pivot, secure using a cotter pin.

NOTE

It may be necessary to make a fine adjustment of the cable pivot before the shifter will engage completely.