

## CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater<sup>TM</sup> Floor Liner from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Jeep Wrangler. The liner are made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners*. However, do not remove the factory-installed carpeting.

Your liners are molded using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liners slick.

## FRONT FLOOR LINER INSTALLATION INSTRUCTIONS FOR JEEP WRANGLER (JL-SERIES)



DRIVER'S SIDE LINER

PASSENGER'S SIDE LINER

PRIOR TO INSTALLING YOUR LINERS, SLIDE BOTH FRONT ROW SEATS COMPLETELY BACK AS THIS WILL ALLOW EASIER ACCESS TO THE FLOOR. WITH THIS DONE, INSTALL THE LINERS, POSITIONING THEM AS SHOWN ABOVE. TAKE CARE THAT THE LINERS ARE SNAPPED ONTO THE FACTORY FLOOR MAT RETAINING POSTS. WITH THE LINERS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.