

WEATHERBEATER[™] FLOOR LINERS

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater[™] Trunk Liner from Husky Liners. Your cargo liner is custom molded to fit your Jeep Compass. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates the "flattening" process will take longer; moving the liner to a heated area will accelerate the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or Glass Plus[®] work well. Use of Armor All[®], Son-of-a-Gun[®] or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR JEEP COMPASS CARGO LINER



Rely only on high-grade car and truck floor mats offered on our virtual shelves.