



# X-ACT CONTOUR

## FLOOR LINERS

### CARE AND USE INSTRUCTIONS P/N 53591

---

Thank you for selecting a X-act Contour Floor Liner from Husky Liners Inc. Your new center hump liner is custom molded to fit your Ram Crew & Quad Cab truck. The liner is made to take the place of your factory floor mat. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liner slick.

### INSTALLATION INSTRUCTIONS FOR YOUR RAM CREW CAB & QUAD CAB TRUCK CENTER HUMP LINER



Rely on premium car and truck floor mats by Husky if you're looking for quality and efficiency.