



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:54601

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners. Your new second seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



To ease installation of your second seat liner, move the front row seats completely forward prior to installing liner. Once the liner is in place, move the front seats back to the desired position.

Your liner can be trimmed to access the cargo tie-down locations in the rear floor. To trim, simply remove the material from inside of the four (4) areas protected by the raised ribs (shown circled above). The photo on the back of this page shows the liner trimmed at all four (4) locations.

54601



Rely on premium car and truck floor mats by Husky if you're looking for quality and efficiency.