

## CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater® Trunk Liner from Winfield Consumer Products. Your new cargo liner is custom molded to fit your Mercedes ML350. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the trunk of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this "relaxing" may take longer; moving the liner to a heated area will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Do not use Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items as these products make the liner slick.

## CARGO LINER INSTALLATION INSTRUCTIONS FOR YOUR MERCEDES ML350



YOUR ML350 HAS TWO (2) CARGO TIE DOWN HOOKS LOCATED AT THE FRONT OF THE CARGO AREA. TO ACCESS TO THE TWO (2) FACTORY TIE-DOWN HOOK LOCATIONS WITH THE LINER IN PLACE. SIMPLY REMOVE/TRIM THE MATERIAL FROM THE AREAS OF THE LINER LOCATED DIRECTLY ABOVE THE HOOKS (AREAS ARE SHOWN DARKENED IN THE DIAGRAM ABOVE). THESE AREAS ARE RECESSED ON THE LINER TO GUIDE TRIMMING. A UTILITY KNIFE WORKS WELL FOR TRIMMING.