

# **HUSKY** **WeatherBEATER™** **Custom Vehicle Floor Protection**

## CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater™ Floor Liner from Winfield Consumer Products. Your new front floor liners are custom molded to fit your vehicle. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

## INSTALLATION INSTRUCTIONS FOR YOUR BUICK ENCLAVE & CHEVROLET TRAVERSE FRONT FLOOR LINERS



TO EASE INSTALLATION OF YOUR FRONT FLOOR LINERS, FIRST SLIDE BOTH FRONT ROW SEATS COMPLETELY BACK TO EXPOSE THE MAXIMUM AMOUNT OF THE FLOORING. NOTE THAT THE FRONT DRIVER'S SIDE LINER ATTACHES TO THE FACTORY MAT RETAINING POSTS. TAKE CARE THAT THE LINER IS SECURELY POSITIONED ON THE FACTORY POSTS WHEN INSTALLED. ONCE LINERS ARE IN PLACE, REPOSITION THE FRONT SEATS AS DESIRED.