



# WEATHERBEATER™ FLOOR LINERS

PT #1407

## CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater® Floor Liner from Husky Liners. Your new rear floor liner is custom molded to fit your Ram 2500/3500 Mega Cab truck. The liner is made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.*** However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

## INSTALLATION INSTRUCTIONS FOR YOUR RAM 2500/3500 MEGA CAB TRUCK 2ND SEAT FLOOR LINER

FRONT OF  
VEHICLE



TO EASE INSTALLATION OF YOUR RAM MEGA CAB SECOND SEAT LINER, MOVE BOTH FRONT ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL YOUR LINER, POSITIONING IT AS SHOWN IN THE IMAGE ABOVE. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.

IF YOUR RAM IS EQUIPPED WITH FRONT ROW BENCH SEATS, THE LINER WILL TUCK UNDER THE AIR VENTS THAT EXTEND OUT ONTO THE CENTER HUMP AREA IN THE BACK SEAT FLOOR. THE AREA THAT TUCKS UNDER THE VENTS CAN ALSO BE TRIMMED AWAY IF PREFERRED. TRIM INSTRUCTIONS ARE INCLUDED ON THE BACK OF THIS PAGE.



## WEATHERBEATER™ FLOOR LINERS

PT #1407

RAM TRUCKS WITH FRONT ROW BENCH SEATING HAVE AIR DUCTS THAT EXTEND OUT ONTO THE CENTER HUMP FLOOR PAN IN THE REAR SEAT. YOUR HUSKY LINER WILL EASILY TUCK UNDER THE AIR DUCTS. HOWEVER, TO MAKE INSTALLATION / REMOVAL OF THE LINER EASIER, YOU MAY DECIDE TO TRIM AWAY THE AREA OF THE LINER THAT TUCKS UNDER THE DUCTING. TO TRIM, A TRIM GROOVE IS MOLDED INTO THE LINER TO AID TRIMMING. THE GROOVE IS LOCATED ON THE OUTER EDGE OF THE RAISE RIB ON THE CENTER HUMP OF THE LINER.



LINER TUCKED UNDER THE AIR VENT ASSEMBLY IN THE 2<sup>ND</sup> SEAT FLOOR PAN.

