



## WEATHERBEATER<sup>®</sup> FLOOR LINERS

PT #1447

Thank you for selecting an WeatherBeater<sup>™</sup> Floor Liners from Husky Liners Inc. Your new liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex<sup>®</sup>, 409<sup>®</sup> and ArmorAll<sup>®</sup> type cleaners work as well.

### INSTALLATION INSTRUCTIONS FOR YOUR SECOND SEAT FLOOR LINERS



TO EASE INSTALLATION OF YOUR NEW SECOND SEAT LINERS, MOVE BOTH FRONT ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL THE LINERS AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED.



## WEATHERBEATER<sup>®</sup> FLOOR LINERS

PT #1447



IF YOUR VEHICLE IS EQUIPPED WITH THE FACTORY 40/20/40 FRONT BENCH SEAT AND YOU HAVE THE FOLD DOWN CUP HOLDERS, IT WILL BE NECESSARY TO TRIM AWAY A PORTION OF THE LINER TO ALLOW ACCESS TO THE REAR FACING CUP HOLDERS. TRIM BY REMOVING THE AREA SHOWN IN THE SKETCH ABOVE. THE MOLDED IN TRIM GROOVE WILL GUIDE THE TRIM. A UTILITY KNIFE OR SCISSORS WORK WELL FOR TRIMMING.



IF YOUR VEHICLE IS EQUIPPED WITH A FACTORY SUBWOOFER LOCATED UNDER THE DRIVER'S SIDE REAR SEAT, YOU WILL NEED TO TRIM YOUR LINER TO ACCOMMODATE THIS OPTIONAL FEATURE. TO TRIM THE LINER, USE THE LOWERED STEP IN THE PART LOCATED BEHIND THE RAISED RIB-WALL AS YOUR TRIMMING GUIDE. CONTINUE TRIMMING OVER THE HUMP USING THE STEP IN THE PART AS YOUR GUIDE.