



WEATHERBEATER™ FLOOR LINERS

PT #1469

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater® Floor Liner from Husky Liners. Your new third seat floor liner is custom molded to fit your Kia Telluride. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR KIA TELLURIDE 3RD SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR 3RD SEAT LINER, MOVE THE 2ND ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL THE LINER, PLACING IT AS SHOWN IN THE IMAGE ABOVE. NOTE THAT THE TONGUE PORTION THAT EXTENDS FORWARD BETWEEN THE 2ND ROW BUCKET SEATS TUCKS BEHIND THE BACK OF THE 2ND SEAT LINER. THE TONGUE SECTION WILL NEED TO BE TRIMMED OFF IN MODELS WITH 2ND ROW BENCH SEATING. SEE THE BACK OF THIS PAGE FOR TRIMMING INSTRUCTIONS.



WEATHERBEATER™ FLOOR LINERS

PT #1469

IF YOUR TELLURIDE HAS 2ND ROW BENCH SEATING YOU WILL NEED TO TRIM YOUR LINER TO ACHIEVE THE CORRECT FIT. TO TRIM, USE A UTILITY KNIFE OR HEAVY SHEARS AND FOLLOW THE MOLDED IN TRIM GROOVE LOCATED JUST IN FRONT OF THE RAISED PROTECTIVE RIB. THIS WILL REMOVE THE SECTION OF THE TONGUE AS SHOWN BELOW.

