



CARGO LINERS

PT #4577

CARE AND USE INSTRUCTIONS

Thank you for selecting a Cargo Liner from Husky Liners Inc. Your new liners are custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory cargo mat. ***For correct fit, it is necessary to remove the factory floor mat before installing your new cargo liner. However, do not remove the factory-installed carpeting.***

Your liner is made from engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.

INSTALLATION INSTRUCTIONS FOR YOUR CARGO LINER

