



# X-ACT CONTOUR

## FLOOR LINERS

### CARE AND USE INSTRUCTIONS – PN: 53611

---

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners Inc. Your new 2<sup>nd</sup> seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats.

***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.*** However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR SECOND SEAT LINER, SLIDE BOTH FRONT ROW SEATS TO THEIR MOST FORWARD POSITION. WITH THIS DONE, INSTALL THE LINER, POSITIONING IT AS SHOWN IN THE IMAGE ABOVE. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT ROW SEATS AS NEEDED.

IF YOUR MEGA CAB TRUCK HAS FRONT ROW BENCH SEATS, YOUR LINER MAY NEED TRIMMING. PLEASE REFER TO THE INFORMATION ON THE BACK OF THIS PAGE.

RAM TRUCKS WITH FRONT ROW BENCH SEATING HAVE AIR DUCTS THAT EXTEND OUT ONTO THE CENTER HUMP FLOOR PAN IN THE REAR SEAT. YOUR HUSKY LINER WILL EASILY TUCK UNDER THE AIR DUCTS. HOWEVER, TO MAKE INSTALLATION / REMOVAL OF THE LINER EASIER, YOU MAY DECIDE TO TRIM AWAY THE AREA OF THE LINER THAT TUCKS UNDER THE DUCTING. TO TRIM, A TRIM GROOVE IS MOLDED INTO THE LINER TO AID TRIMMING. THE GROOVE IS LOCATED ON THE OUTER EDGE OF THE RAISE RIB ON THE CENTER HUMP OF THE LINER.



**LINER TUCKED UNDER THE AIR VENT ASSEMBLY IN THE 2<sup>ND</sup> SEAT FLOOR PAN.**

