



# X-ACT CONTOUR

## FLOOR LINERS

### CARE AND USE INSTRUCTIONS – PN:53711

---

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners Inc. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

When installing your floor liners make sure that the floor mat retention twist-locks on your vehicle floor install thru the clips in your floor liners and turn the twist lock to secure on the driver's side. Secure the passenger's side by screwing the liner retention screw into the carpet and align the liner over the hole in the liner and screw on the retention screw cap (see detailed instruction on the back of this page).

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER



# 53711

In your packaging you will find a component bag that includes a fastener designed to aid in securing your passenger side liner in position. Remove the fastener from the bag and unscrew the cap from the base (see image 1 below). Next, insert the fine threaded portion of the base into the hole in the passenger side liner, inserting it in from the back side of the liner (see image 2 below). With this done, position the liner in the vehicle and, using a coin, screwdriver or similar tool, screw the base of the fastener into the carpeting (see image 3). Lastly, as shown in image 4, install the cap back onto the base, tighten only until the cap meets resistance. Do not over tighten.

