



## X-ACT CONTOUR® FLOOR LINERS

PT #5532

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new third seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

### INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR THIRD SEAT FLOOR LINER



TO INSTALL LINER, FIRST FOLD & FLIP BOTH SECOND ROW SEATS FORWARD. WITH THIS DONE, POSITION LINER SO THAT THE REAR OUTER EDGES MATCH UP TO THE INTERIOR TRIM PANELS IN VEHICLE. PLEASE NOTE THAT THE SEAT BELT POSITIONED ALONG THE DRIVER'S SIDE TRIM PANEL WILL FIT INTO THE PRE-TRIMMED HOLE IN THE LINER (SHOWN ABOVE CIRCLED). THE LINER IS SLIT TO ALLOW THE SEAT BELT TO PASS THROUGH THE LINER AND INTO THE HOLE. LASTLY, WITH THE LINER IN PLACE, FOLD THE SECOND ROW SEATS BACK INTO POSITION. THE SEAT LEGS WILL FASTEN THROUGH THE LINER INTO THE FLOOR IN THE 4 TRIMMED HOLES.