



X-ACT CONTOUR® FLOOR LINERS

PT #5549

CARE AND USE INSTRUCTIONS

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new front floor liners are custom molded to fit your vehicle. The liners are made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.*** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR X-ACT CONTOUR FRONT FLOOR LINERS



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO INSTALL YOUR LINERS, FIRST SLIDE THE FRONT ROW SEATS COMPLETELY BACK TO EXPOSE THE MAXIMUM AMOUNT OF THE FLOOR PANS. THEN, INSTALL YOUR LINERS, POSITIONING THEM AS SHOWN ABOVE. WITH THE LINERS INSTALLED, REPOSITION THE SEATS AS DESIRED. NOTE THAT THE DRIVER'S SIDE LINER ATTACHES TO THE FACTORY TWIST-LOCK FASTENERS.

Discover other car and truck floor mats on our website.