

EXPLORER**REAR MUD GUARD INSTALLATION INSTRUCTIONS**

Please read instructions thoroughly before installation.

Tools Required

- 9/32 Socket

Package Contents

- Rear Mud Guard
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5950 DS and 5950 PS).

1. Clean and degrease the mud guard location area on the fender before installation. Remove existing fasteners from locations A, B, C and D.
2. Attach mud guard to rear fender with factory fastener at locations A, B, C and D, check fit and make sure mud guard is parallel to ground before tightening. Install clip where shown.

