



Wheel Well Guards

7900 - Installation Instructions

2007-13 Chevrolet Silverado/GMC Sierra 1500
2007-14 Chevrolet Silverado/GMC Sierra 2500/3500

PACKAGE CONTENTS:



Wheel Well Guard
Driver's Side (1)



Wheel Well Guard
Passenger's Side (1)



U-Clips (8)



SEM Screws (8)

TOOLS REQUIRED:

- Phillips Head Screwdriver
- Drill Motor & 1/8" Drill Bit (For GMC Sierra only)

VEHICLE PREPARATION:

Your vehicle's rear fender wells should be cleaned prior to the installation of your new Wheel Well Guards.



Installation

Read all directions thoroughly prior to the installation of your Wheel Well Guards.

A, B, C & D are pre-drilled fastener locations for installation.



1. Verify that you are installing the correct Wheel Well Guard by checking the part no. located on the backside of the part.

- 7900 DS installs on the driver's side.
- 7900 PS installs on the passenger's side.



2. Install 2 U-Clips over the Wheel Well Guard's pre-drilled holes at locations B & C.

NOTE: The U-Clips need to be installed over the Wheel Well Guard lip with the threaded side of the U-Clip up.



3. Insert the Wheel Well Guard into the rear wheel well opening over the tire.

NOTE: It is not necessary to remove the tire.



4. Push The Wheel Well Guard up into the wheel well opening.



5. Insert the lower flap sections of the Wheel Well Guard into the fender well behind the fender well lip. Perform this step for both the front and rear lower flap sections.



6. Tuck the remaining portion of the Wheel Well Guard behind the fender lip all the way around the fenderwell opening.



7. Align the U-Clip holes with the factory fender holes at locations B & C. Install #10 SEM screws under the fender well lip, through the fender sheet metal and into the U-Clips at location's B & C. Leave screws loose until all fasteners are installed.



8. Install #10 SEM screws at locations A & D through the Wheel Well Guard, through the fender sheet metal and into U-Clips (see below).



Do not clip the U-clip over the sheet metal. The U-Clip functions as a "nut" and is placed on the backside of the sheet metal.

NOTE: FOR GMC SIERRA ONLY: Prior to installing fasteners you must drill 1/8" holes through the sheet metal at locations A & D. Use the pre-drilled fastener locations A & D as a template. Drill 1/8" holes and install #10 SEM screws.



9. Once all fasteners at locations A, B, C, & D are installed, tighten with a Phillips head screwdriver.

10. Finish by tightening all fasteners.

Repeat steps 1-10 for the other side of the vehicle.