

Thank you for selecting a WeatherBeater® Floor Liner from Winfield Consumer Products. Your new center hump liner is custom molded to fit your Chevrolet Silverado/GMC Sierra Extended and Crew Cab trucks. The liner is made to take the place of your factory floor mat. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner*. However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liner slick.

## CHEVROLET SILVERADO & GMC SIERRA EXTENDED AND CREW CAB TRUCK CENTER HUMP LINER INSTALLATION INSTRUCTIONS

