



## WEATHERBEATER™ FLOOR LINERS

PT #9401

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater™ Floor Liner from Husky Liners. Your new front floor liners are custom molded to fit your Ram Quad Cab truck. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

### INSTALLATION INSTRUCTIONS FOR YOUR RAM CREW CAB FRONT FLOOR LINERS



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR NEW FRONT LINERS, MOVE BOTH FRONT ROW SEATS TO THEIR MOST REARWARD POSITION. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED. TAKE CARE THAT THE LINERS ARE SNAPPED OVER THE FACTORY RETENTION POSTS.



## WEATHERBEATER™ FLOOR LINERS

PT #9401

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater™ Floor Liner from Husky Liners. Your new 2<sup>nd</sup> seat liner is custom molded to fit your Ram Quad Cab truck. The liner is made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.*** However, *do not remove the factory-installed carpeting.*

Your liner is molded using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

### SECOND SEAT FLOOR LINER INSTALLATION INSTRUCTIONS FOR RAM QUAD CAB TRUCKS



PRIOR TO INSTALLING YOUR 2<sup>nd</sup> SEAT LINER, SLIDE BOTH FRONT ROW SEATS COMPLETELY FORWARD. WITH THIS DONE, INSTALL THE LINER, POSITIONING IT AS SHOWN ABOVE. ONCE THE LINER IS IN PLACE, REPOSITION THE FRONT SEATS AS DESIRED. THE LINER TUCKS UNDER THE AIR DUCTS THAT ARE LOCATED UNDER THE BACK OF THE FRONT SEATS (SEE PHOTO ON BACK OF PAGE).



**WEATHERBEATER™  
FLOOR LINERS**

**PT #9401**



Learn more about car and truck floor mats we have.